

Bedienungsanleitung gültig für Art.-Nr.: 070-50006

»Halogen-Frontlicht mit Anschluss für Seitenläufer«

D

Technische Daten und Hinweise


- ▶ Glühlampe 6V. 2.4W, Halogen
- ▶ Lichtstärke min. 10 Lux
- ▶ Geprüft und zugelassen nach StVZO
- ▶ inkl. Überspannungsschutz
- ▶ wasserdicht
- ▶ inkl. Halter

Auswechseln der Glühlampe

- ▶ Heben Sie den Halter, wie in der Zeichnung dargestellt, an. Drehen Sie den das Gehäuse der Lampenfassung, bis es sich herauslösen lässt. Entnehmen Sie die defekte Glühlampe und tauschen Sie sie aus.



Anschluss der Kabel



Instruction-manual valid for art.-nr.: 070-50006

GB


»Halogen-frontlight with connection for dynamo«

Technical facts and references

- ▶ with halogen bulb (6V. 2.4W)
- ▶ Vehicular optical test requirement: German standard
- ▶ waterproof
- ▶ 10 Lux-light-power
- ▶ with voltage security system
- ▶ with WB-01S bracket

Exchanging the bulb

- ▶ Lift the bracket to a certain degree (according to the sketch), then you can rotate the bulb holder to replace the defect bulb.



Cable connector instruction

